



**GOOD
GRIPS[®]**

**3-in-1 Adjustable
Potato Ricer**

USE & CARE

www.oxo.com



USE & CARE

1. Select purée consistency by lining up notch on rotating disk with icons on Ricer.
2. For firm vegetables (potatoes, carrots, etc.) boil until tender and cut into pieces that will fit into the Ricer.
3. For soft fruits, cut into pieces that will fit into the Ricer. Eggs can be placed in Ricer whole.
4. Rest the Ricer on a bowl or saucepan. Lift the top handle, place food pieces in the barrel, and squeeze the handles together.



CLEANING INSTRUCTIONS

1. To remove rotating disk, line up notch on disk with arrow icon on Ricer.
2. Hold disk with your thumb directly beneath Ricer handles. Pull off one side of disk with your thumb. Disk should come off easily.
3. To replace disk on Ricer after cleaning, line up notch on disk with arrow icon on Ricer.
4. Hold disk with your thumb directly beneath Ricer handles. Push on the side of the disk that is directly beneath the pot rest. Then use your thumb to push on the side of the disk that is directly beneath the Ricer handles.
5. Rotate disk clockwise to lock into place.