

## MICROWAVE EGG COOKER USE AND CARE

---

1. Ensure base is securely on Cooker body. Open lid and spray inside with non-stick cooking spray.  
**Scrambled egg:** Crack in 1-2 eggs, add milk or water and spices as desired. Use a fork to whisk directly in Cooker.  
**Fried egg:** Crack in 1 egg.
2. Close lid, use handle to lift Cooker and place in microwave. Cook as recommended in chart, until egg is set at desired doneness.
3. Use handle to remove Cooker from microwave.
4. Hold tab on serving base and lift Cooker by handle to remove.
5. Use serving base to transfer egg to bread or plate.

### To disassemble to clean:

To remove lid, push lid open, over rotating past the natural stopping point.

To replace, line up hinges on lid and body and push to snap into place.

Top-rack dishwasher safe

This product is intended for use in the microwave.

It is not for oven or stovetop use.

## COOKING CHART

INGREDIENT	TIME
1 Egg, scrambled	30-75 seconds
2 Eggs, scrambled	45 seconds-2 min
Egg Substitute, 3 Tbsp	30-60 seconds
Egg Whites, ½ cup	1-2 min
1 Egg, fried	25-40 seconds

We've tested our products in microwaves big and small to come up with an approximate cooking time. All microwaves are different, and some will cook faster than others. So get to know how long it will take in your microwave - it may need more or less than the time we've suggested. You'll know it's done when the egg is set to desired doneness.